

User Manual



Warning

Please follow safety instructions in this booklet to avoid seriously injuries or even death.

Important

Please read this manual carefully and follow the instructions. Only authorized people can use this Dryer. For any question please contact REKTÖR MAKİNA.

Index

Foreword	: 1
Warning signs	: 2
Safety rules	: 3
Operating Instructions	: 4
Pre-Operation Inspection	: 5
Install and transport	: 6
Usage and Storage	: 7
Working Life Time and Noise Declaration	: 8
Technical Specifications	: 9
Maintenance Programme	: 10
Troubleshooting	: 11
Drying Room	: 12
Fan and Heat Isolation	: 13
Cables	: 14
Cable Connections for additional Fans	: 15
Removable Parts	: 16-17
Air Sealing Parts	: 18-19
Technical Drawings	: 20-25
Control Panel (Time Relay)	: 26
Control Panel (Dehumidifier)	: 27-28
Control Panel (Dryer)	: 29-30
Electric Scheme	: 31

Warning Signs




Please avoid
contact with
liquids



Do not run the
Dryer with peeled
cables



Avoid Cable
Jams



Do not approach
with sharp and
spike materials



For Repair and
Maintenance Call
Technical
Service



**COMPRESSED
GAS**



**POISON
GAS**



Safety Rules



Warning

Please follow safety instructions in this booklet to avoid seriously injuries or even death. Please read safety instructions this manual carefully before operating the Dryer. Avoid dangerous situations. Before operationg the Dryer, always make safety inspections. Always inspect the working area of the Dryer (electrical connection and cable). Use the Dryer only for its work purpose. Please follow all instructions in the user manual as well as all signs on the Dryer. Please study the Dryer for safety opearation.

Electrical Shock Hazard

This machine has a ground connection to the power outlet. Always connect the grounding cable and check your grounding line. If the grounding cable is not connected and if there is electricity leakage, machine gives electric current to out side. This Dryer has no electric isolation and can not protect against electrical contact. Please keep away from the Dryer in case of electrical contact. Otherwise, there will be an electrical shock and seriously injures and even death.

Hazards caused by failures of the Dryer

Please do not operate a defective Dryer.

Wrong operating hazard: Please do not leave the Dryer unattended. Dryer operated by unauthorized person can cause seriously injures or even death.

Usage Instructions



Basic Items

The usage instruction section, includes all operating instructions. It is the responsibility of the operator to follow the safety instructions.

It is not safe to use the Dryer for purposes other than its purpose mentioned herein. If the Dryer is used by more than one operator, each operator has to follow all instructions; before operating the Dryer, always make safety necessary inspections. Always make a function test. Always inspect the working area of the Dryer.

Always check these points before starting: electrical connection point of machine, fuse, connection point of cables in electrical panel, attachments of cables, socket. If there is a loose connection, these things warm up and can cause fire. If there is a loosening or heating, it must be repaired by authorized persons.

Electrical cables should not be added in the drying room. There should be no fuse and socket in drying room.

Usage Instructions

The Dryer is designed for heating, dehumidifier and drying a isolated closed area with a volume of 100m³.

Besides, the Dryer can be used as a dehumidifier for 2000m³ . (Room without isolation).

Pre Usage Inspection Process



Basic Item

A Pre-Usage Inspection, is a visual control made by the operator with control and safety equipment (Electric insulated hand tools - Screwdriver, Pliers, Control pen, Glove-) before operating the Dryer. Please check each item the list next page. In case of any changes comparing to factory defaults and / or defect caused by producer, make sure that the Dryer will not be operated.

It is clearly mentioned in this user manual, that the repairment of the Dryer should be made only by qualified technicians. After the repairment, the operator should make the routine pre-operationg inspections.

Pre-Usage Inspection Process

Make sure that the whole user manual is always readable and fully available.
Make sure that all security tags are in its place as shown in the tag section.

Please check following items for damage, improper installation or missing parts and check if anything is changed.



1. Make sure that all removable parts are in its place
2. Make sure that the Power Cord is connected to grounded fuse
3. Open the air output vent with the lever. Leave at least 50cm space for the suction input and blow output.
4. Fix the dryer on a plain ground.



Install and Transport

Install : Fix the Dryer on a plain ground. To fix the Dryer on a plain ground, lock the two frontwheels.



After all security inspections, connect the power cord of machine to a 380V grounded electric fuse



Switch the Dryer on as shown in the image.

Transport

Make security precaution before transporting the Dryer. While moving/transporting the Dryer please consider that its weight is 150kg. The transportation is dividen into three main processes.



1. Moving/Transporting on a plain ground: After unlocking the wheels you can move the Dryer via transportation handle.



2. Moving/Transporting on a uneven ground: Make security precaution and lift the Dryer on its big wheels move the Dryer.



3. Moving/Transporting by by carrying: This macine can be carried by two persons. Carry the Dryer as shown in the Picture. Lift the macine on its big wheels and and The second person can lift the Dryer up via the small front wheels.



4. Long Distance Transportation: For Long distance Moving/Transportation put the Dryer in its crate. To avoid any damage during the transportaion fix the




Usage and storage



R 407c What to consider

RM 55000 dryer heat pump works with compressed freon gas (Chlorofluorocarbon compound) in a closed circuit on the heatexchanger. Damagin the heatexchangers during usage or storage may cause leaking freon gas (Chlorofluorocarbon compound). When hitting the heatexchanger with an sharp metal may cause compressed freon gas (Chlorofluorocarbon compound) leak.



R 407c: It is liquid gas and compressed. In case of contact with flame or extremely hot metal surfaces can be released toxic and corrosive products. The steam of it is heavier than oxygene and reduces oxygene in the air. Inhaling freon gas can cause heart irregularities, consciousness loss. Contact with eye and skin can cause frostbite.

First aid for R 407 c Freon Gas Injuries

When contact with eyes, wash it out with plenty of water. If the freon viciom can not breath, provide the patient with artificial respiration. If spilled or leaked outdoor; hold it against the wind. If spilled or leaked indoor; empty the place and deploy gas through a ground level ventilation. Do not smoke and do not start any internal-combustion engine. Keep away flames and heatet elements.



Working Life Time and Noice Declaration

Working Life

- 1.Heat Pump 32.000 hours
2. Fan Engine 17.280 hours

When working life has of a spare part is over, it should be replaced with a new one in order to make the Dryer work again.

Note: Sparepart replacement should only be done by an authorized technician.

Noice Level

V 4.4 – 71-89 dB

V 6.1 – 71-89 dB

V 9.0 - 75 -89 dB



Technical Specifications

It is the policy of Rektör Makine to improve its products continuously. Rektör Makine has the right to change the product specifications without prior notice.

Rm 55.000	V 4.4	V 6.1	V 9.0
Dimension (cm)	76-80-125	74-86-135	83-80-183 cm
Weight	180 Kg	190 Kg	264 kg
Energy Consumption	4.4 Kw/h	6.1 Kw/h	9 Kw/h
Current Draw	10.1 Ampere	14 Ampere	22 Ampere
Initial Current	55 Ampere	65 Ampere	96 Ampere
Power Supply	342-462-V-3-50 Hz 414-506-V-3-60 Hz	342-462-V-3-50 Hz 414-506-V-3-60 Hz	342-462-V-3-50 Hz 414-506-V-3-60 Hz
Effective area (heated)	70 m ³	100 m ³	130 m ³
Effective area (non-heated)	2000 m ³	2000 m ³	2000 m ³
Dry air output	% 18 rh	% 18 rh	% 18 rh
Air Flow			
Dry Air Flow	2800 m ³ /h	2800 m ³ /h	2800 m ³ /h
Warm Air Flow	4000 m ³ /h	4000 m ³ /h	8000 m ³ /h
Total Air Flow	6800 m ³ /h	6800 m ³ /h	10800 m ³ /h
Operating Temperature Range			
Max Heating Capacity	45 °C	45 °C	45 °C
Max Working Temperature	50 °C	50 °C	50 °C
Min Working Temp.	5 °C	5 °C	5 °C
Heating Capacity	6.400 kcal/h	12.000 kcal/h	25.000 kcal/h
Operating Humidity Range			
Adjustable humidity range	%0 / %100	%0 / %100	%0 / %100
Max. Operating Humidity	%100	%100	%100
Min. Operating Humidity	%20	%20	%20
Dehumidifying Capacity	20 °C %60 - 216 lt/daily	20 °C %60 - 265 lt/daily	20 °C %60 - 320 lt/daily
Max. Dehumidifying Cap.	45 °C %60 - 360 lt/daily	45 °C %60 - 480 lt/daily	45 °C %60 - 720 lt/daily



Maintenance Programme



Daily Maintenance

Machines with air filter, should be cleaned daily. The cleaning should be made with high pressure water or high pressure air.



Monthly Maintenance

Remove the air input filter and clean the aluminium surfaces with high pressure water or vacuum cleaner.



Annual Maintenance

The annual maintenance should be made by an authorized technician. The heat exchangers should be removed and cleaned. The machine is tested for gas and performance.

Note: The maintenance intervals may vary depending on the pollution rate.
“Beware of sharp parts while cleaning.”




Troubleshooting




Fault Detection : In case of a fault, check switch and the warning mechanisms in the Electric Panel. Shown in the images and explanations Detect the Fault.

1. The Fan Engines will be disable if the Fuse is switched off. To re-operate the Fan Engines switch the Fuse Switch to on.
2. Check the Heat-Pump Engine protection switch, if the switch is on the 0 position, the protection switch is switched off and the electrical cuircuit has been interrupted. To re-operate the Heat-Pump turn the switch to position 1.
3. The Contactor is used to transfer power.
4. If the Gren-Led On the MKS 01 is off, there is a electricity problem.
5. When the Heat-Pump Engine re-operates, first the “on led” lits and then the “out” led lits. When these leds are not lit, that means that a electrical fault has occured.
6. Will only engaged below certain temperatures and avoids the dryer to freeze.
7. In case of high current, the thermal switch cuts the circuit and provides protection and engages it self again.
8. Fan relay. When the fan relay is broken only machine’s fans will not work. The machine's internal motors rarely work (e.g; working- stop- working- stop ...). So that this part is broken. If this part is broken again after changing, the fans are faulty.



Drying Room



Drying Room

The Drying Room should not be bigger than 100m³ . For Rooms with more than 100m³ a second dryer is required. The volume of the room depends on the ceiling height. The ceiling should not be higher than 2,5m.

For Example; A room with a ceiling height of 2,5m should be max. 40m². $40 \times 2,5 = 100\text{m}^3$

Fan and Heat Isolation

External Fan (With Automatic Blinds)



2 Fans with automatic blinds and air sealing feature should be mounted like shown in the drawing. The Fans should be positioned diagonally. Fans are operating connected to the

dryer. If required the Dryer activates the Fans. One Fan operates as air input fan and the other air output fan. The purpose is to balance the heat in the room.

External Fan (Heat Recovery)

The heat recovery fan should be mounted on the ceiling of the drying room like shown in the drawing.

It is positioned on the ceiling of the drying room at the right or left corner. There must be min. 50 cm clearance on the sides of the fan.. Fans are operating connected to the dryer. If required the Dryer activates the Fans. The moist air is blown out by the fan. The heat air in the room returns. And heat loss is stopped.



Isolation

When preparing a drying room, the inside of the room should be isolated.

Drying Process takes more time in a Room without isolation.
Less Heat-Loss equals short Drying Process.




Compressed Styrafoam

The insulation is a 40 density 3 cm compressed foam alloy. It is used for hot, cold and sound insulation.

Compressed Styrafoam is mainly used for outdoor cold and heat isolations.

To avoid heat-loss in the drying room all surfaces (floor, walls and ceiling) of the drying room should be covered with compressed styrafoam. Alternatively to avoid possible oppression on the floor, materials like sandwich panels can be used.

Cables



 -Ground

N - Neutral

L1 - 1. Phase

L2 - 2. Phase

L3 - 3. Phase

Fan Cables



N - Neutral

L1 - Phase

Cable Connections for additional Fans

Connecting cables


L1 - Brown cable

N4 - Blue cable

External Fan (With Automatic Blinds)



External Fan (Heat Recovery)




Removable Parts

During the maintenance of the Dryer, remove only the parts 3 and 9. All other parts should be removed by authorized technician. The order removing process is shown below. Do not operate the Dryer during the remove process. Disconnect electrical connection. Close the fuse.

Things to do when removing parts

Remove the screws the held the parts together. Remove the parts in the order shown below. To re attach the parts follow the order backwards. Wthen removing part nr.6 (Left Cover) water discharge hose and on of switch as well as the power cables should be removed. Please check the electric panel knowledge before removing cables.

For V 4.4 ve V 6.1




Part Names

- 1- Carrying handle
- 2- Top cover
- 3- Supply register
- 4- Main body
- 5- Right cover
- 6- Left cover
- 7- Big wheels
- 8- Small wheels
- 9- Exhaust register

Detach order

- 3- Supply register
- 9- Exhaust register
- 1- Carrying handle
- 2- Top cover
- 7- Big wheels
- 5- Right cover
- 6- Left cover

• V 9.0



Part Names


- 1- Carrying handle
- 2- Top cover
- 3- Supply register
- 4- Main body
- 5- Right cover
- 6- Left cover
- 7- Big wheels
- 8- Small wheels
- 9- Exhaust register

Detach Order

- 3- Supply register
- 9- Exhaust register
- 1- Carrying handle
- 2- Top cover
- 7- Big wheels
- 5- Right cover
- 6- Left cover

Air Sealing Parts


- V 4.4 ve V 6.1



Part Names

- 1- Back coating
- 2- Right inner accent
- 3- Left inner accent
- 4- Bottom inner accent
- 5- Front coating

- **V 9.0**





Part Names

- 1- Back coating
- 2- Right inner accent
- 3- Left inner accent
- 4- Bottom inner accent
- 5- Front coating


Technical Drawings






• V 4.4










• V 6.1









• V 9.0







MULTIFUNCTION ELECTRONIC TIME RELAY

ERT/ERTC-01

ERT/ERTC-01 is a microcontroller controlled programmable time relay device with a wide range of time scale designed to operate in one of 4 different functions that are **On delay, Off delay, Down timer, Flasher** modes. Output relay is controlled by set value that can be set between 1.0 sec – 100 hours. Programmed function and set values are recorded at non-volatile memory. Functions and set values can be programmed easily by buttons on the front panel. ERT/ERTC-01 has optically isolated Start, Stop and Reset inputs.

Functions:

On Delay: In the On Delay mode, after the device is energized, the timer starts to count up and when it reaches the adjusted time, the relay is energized. (**dLYOn**)

Off Delay: In the Off Delay mode, after the device is energized and with start input, the relay is energized and becomes de-energized at the end of the time adjusted by the user. (**dLYOFF**)

Down Timer: In the Down Timer mode, after the device is energized, the down counter starts to count down from the time adjusted by the user and when it reaches zero, the relay is energized. (**dO Cnt**)

Flasher: In the Flasher mode, after the device is energized, when **tOFF** time ends the relay is energized and becomes de-energized at the end of the **tOn** delay (**FLSHer**). The starting mode of the flasher mode can be chosen with **StOFF** or **StOn**. In the **StOFF** mode flasher starts with **tOFF** and energized after the **tOFF** value, then continues to **tOn** mode. In the **StOn** mode flasher starts with **tOn** and deenergized after the **tOn** value, then continues to **tOFF** mode. The Flasher function is continuously repetitive.

Inputs: Start input is used to begin counting. Stop input is used to end counting and Reset input is used to clear counter in **dLYOn**, **dLYOFF** and **FLSHer**. In **dO Cnt** mode reset, sets the **dO Cnt** value. One of this three inputs activated by connecting them to GND.

Function Select:

The device is programmed by pressing the SET button for 3 secs. Then program menu starts with blinking of **dLYOn**. With UP and DOWN button desired mode **dLYOn**, **dLYOFF**, **dO Cnt** or **FLSHer**, and the mod led blinks. After pressing the SET button display stops blinking that this mode is chosen. Pressing once to SET button shows the old time value of this mode with blinking and this could be adjusted with UP and DOWN button. Pressing to UP or DOWN button continuous, increases or decreases the left digit. For all the other functions, the left digit is changed the same way. After adjusting the time value, pressing the SET button stops the display blinking, but led button still blinks (Note that this setting operations need a few steps more for **FLSHer** mode). After pressing the SET button last time mod led stops blinking, desired mod and value are set and written to non-volatile memory.

Device can be started to counting with start input. With stop input device stops counting until stop input is deactivated. Reset input resets the time values. Device can be started with pressing set and up button at same time (same function with start input). Pressing set and down button at the same time stops counting. (same function with stop input). Pressing DOWN and UP button at the same time resets counting (same function with RESET input).



Precautions For Installation and Safe Use

Failure to follow those instructions will result in death or serious injury.

- Disconnect all power before working on equipment.
- When the device is connected to the network, do not remove the front panel.
- Do not try to clean the device with solvent or the like. Only clean the device with a dried cloth.
- Verify correct terminal connections when wiring.
- Electrical equipment should be serviced only by your competent seller.
- Only for rack panel mounting.

⚠ No responsibility is assured by the manufacturer or any of its subsidiaries for any consequences arising out of the use of this material.


Programming Diagram




Technical Data

Operating Voltage(Un)	: 230 V AC / 120 V AC
Operating Range (ΔU)	: 190 - 260 V AC / 90 - 140 V AC
Operating Frequency (f)	: 50/60 Hz
Power Consumption	: < 3 VA
Output Contact	: 1 Change-Over 8A/2000VA
Error	: ± 0.5 or ± 20 msec. (Which is higher)
Repetition Error	: ± 0.1
Reset Time	: ≤ 80 msec.
Ambient Temperature	: -5°C ; $+50^{\circ}\text{C}$
Display	: Red LED display
Dimension	: PK-20 (ERTC-01), PR-18 (ERT-01)
Equipment Protection	: Double Insulation (II)
Degree of Protection	: IP 40 (Front Panel)
Box Material	: IP 20 (Terminal Covers)
Wire Cross section (for terminal)	: Nonflammable, (Yellow Certificate no:187982)
Weight	: 2.5 mm ²
Installation	: 0.25 kg
Package Dimensions	: Rail Mounting (ERTC-01), Class III (ERT-01)
Package Weight	: 22 x 18 x 18.5 cm (ERTC-01)
Pcs Per Package	: 37 x 21.5 x 17 cm (ERT-01)
	: 4 Kg (ERTC-01), 4.5 Kg (ERT-01)
	: 16

Dimensions (ERTC-01):



Dimensions (ERT-01):



*No need of a ventilator in the installation area

XT110C - XT111C - XT110D - XT111D

Single Stage Digital Controller with Multi Probe Input



1. GENERAL WARNING

1.1 PLEASE READ BEFORE USING THIS MANUAL

- This manual is part of the product and should be kept near the instrument for easy and quick reference.
- The instrument shall not be used for purposes different from those described hereunder. It cannot be used as a safety device.
- Check the application limits before proceeding.

1.2 SAFETY PRECAUTIONS

- Check the supply voltage is correct before connecting the instrument.
- Do not expose to water or moisture: use the controller only within the operating limits avoiding sudden temperature changes with high atmospheric humidity to prevent formation of condensation
- Warning: disconnect all electrical connections before any kind of maintenance.
- The instrument must not be opened.
- In case of failure or faulty operation send the instrument back to the distributor or to "DIXELL S.p.A." (see address) with a detailed description of the fault.
- Consider the maximum current which can be applied to each relay (see Technical Data).
- Ensure that the wires for probes, loads and the power supply are separated and far enough from each other, without crossing or intertwining.
- In case of applications in industrial environments, the use of mains filters (our mod. FT1) in parallel with inductive loads could be useful.

2. GENERAL DESCRIPTION

The XT110C, XT111C and XT110D, XT111D (DIN RAIL format) are single-stage ON/OFF controllers for temperature, humidity and pressure applications with direct or inverse action, user-selectable. The analogue input type can be set by parameter between the following, according to the model:

- PTC, NTC;
- PTC, NTC, Pt100, Thermocouple J, K, S;
- 4-20mA, 0-1V, 0-10V.

3. FIRST INSTALLATION

3.1 PROBE SETTING



The pre-set probe type is written on the label of the instrument, see picture. If it is different from the probe that has been used, set the probe following procedure below

3.1.1 How to set the probe.

- Enter the programming menu by pressing the **SET+ ▾** for 3s.
- Select the **Pbc (Probe configuration)** parameter and push the **SET** key.
- Set the kind of probe:
 - Controller for temperature:** Pt= Pt100, J= J thermocouple, c= K thermocouple, S= S thermocouple; Ptc = PTC; ntc = ntc.
 - Controller with current or voltage inputs:** cur=4-20mA, 0-1= 0-1V, 10= 0-10V
- Push the **SET** key to confirm it.
- Switch the controller **off** and **on** again.

NOTE: Before proceeding check and, if necessary, set with appropriate values the **Minimum Set Points (LS1 e LS2)** and **Maximum Set Points (US1 e US2)**. See also the paragraphs concerning the programming.

4. FRONT PANEL COMMANDS




SET: To display and modify target set point; in programming mode it selects a parameter or confirm an operation.

TO SWITCH THE INSTRUMENT ON/OFF: If the function is enabled (par. onF=yES), by pressing the SET key for more than 4s the controller is switched OFF. To switch the instrument on again press the SET key.

▴ **UP:** in programming mode it browses the parameter codes or increases the displayed value. Hold it pressed for a faster change

▾ **DOWN:** in programming mode it browses the parameter codes or decreases the displayed value. Hold it pressed for a faster change



KEY COMBINATIONS:

- ▴ + ▾ To lock & unlock the keyboard.
- SET + ▾ To enter in programming mode.
- SET + ▴ To return to the room temperature display.

4.1 USE OF LEDS

A series of light points on the front panels is used to monitor the loads controlled by the instrument. Each LED function is described in the following table.

LED	MODE	FUNCTION
	ON	Output relay enabled
LED1	Flashing	- Programming Phase (flashing with LED2)
LED2	Flashing	- Programming Phase (flashing with LED1)
E.S.	ON	Energy saving activated by digital input
	ON	- ALARM signal
	ON	- In "Pr2" indicates the parameter is also present in "Pr1"

4.2 TO SEE THE SETPOINT

- Push and release the **SET** key to see the Set point value;
- To come back to the normal display push again the **SET** key or wait 10s.

4.3 TO CHANGE THE SETPOINT

- Hold pushed the **SET** key for 3s to change the Set point value;
- The value of the set point will be displayed and the LED1 & 2 start blinking;
- To change the Set value push the **▴** or **▾** arrows within 10s.
- To memorise the new set point value push the **SET** key again or wait 10s.

4.4 TO ENTER THE PARAMETERS LIST "PR1"

To enter the parameter list "Pr1" (user accessible parameters) operate as follows:

- Push for 3s the **SET + ▾** keys (LED1 & 2 start blinking).
- The controller will display the first parameter present in the Pr1 menu.

4.5 TO ENTER THE PARAMETERS LIST "PR2"

The "Pr2" parameter list contains the configuration parameters. A security code is required to enter it.

- Enter the "Pr1" level, see above paragraph.
- Select "Pr2" parameter and press the **SET** key.
- The "PAS" flashing message is displayed, shortly followed by "0 -" with a flashing zero.
- Use **▴** or **▾** to input the security code in the flashing digit; confirm the figure by pressing **SET**.

The security code is "321".

- If the security code is correct the access to "Pr2" is enabled by pressing **SET** on the last digit.

Another possibility is the following:

After switching ON the instrument, within 30 seconds, push **SET + ▾** keys together for 3s: the Pr2 menu will be entered.

4.6 HOW TO MOVE A PARAMETER FROM THE "PR2" MENU TO "PR1" AND VICEVERSA.

Each parameter present in "Pr2" MENU can be removed or put into "Pr1", user level, by pressing **SET + ▾**. In "Pr2" when a parameter is present in "Pr1" the LED is on.

4.7 HOW TO CHANGE A PARAMETER

To change a parameter value operates as follows:

- Enter the **Programming mode**
- Select the required parameter.
- Press the **SET** key to display its value.
- Use **UP** or **DOWN** to change its value.
- Press **SET** to store the new value and move to the following parameter.

TO EXIT: Press **SET + UP** or wait 15s without pressing a key.

NOTE: the set value is stored even when the procedure is exited by waiting the time-out to expire.

4.8 HOW TO LOCK THE KEYBOARD



- Keep pressed for more than 3s the **▴** and **▾** keys.
- The "POF" message will be displayed and the keyboard will be locked. At this point it will be possible only to see the set point or the MAX o Min temperature stored
- If a key is pressed more than 3s the "POF" message will be displayed.

4.9 TO UNLOCK THE KEYBOARD

Keep pressed together for more than 3s the **▴** and **▾** keys, till the "Pon" message will be displayed.

4.10 ON/OFF FUNCTION

TO SWITCH THE INSTRUMENT ON/OFF: If the function is enabled (par. onF=yES), by pressing the SET key for more than 4s the controller is switched OFF. To switch the instrument on again press the SET key.

5. PROBES AND MEASURING RANGE

Probe	Down Scale	Full Scale
NTC	-40°C / -40°F	110°C / 230 °F
PTC	-50°C / -58°F	150°C / 302°F
Pt100	-200°C / -328°F	600°C / 1112°F
TcK	0°C / 32°F	1300°C / 1999°F
TcJ	0°C / 32°F	600°C / 1112°F
TcS	0°C / 32°F	1400°C / 1999°F

15. DEFAULT SETTING VALUES

COD	Name	Range	°C/°F	Lev
Set	Set point	LS1÷US1	0/32	-
Hy1	Differential	-Full Sc./ Full Sc.	-1/-2	Pr1
LS1	Minimum set point	Down Sc./ Set	min	Pr2
US1	Maximum set point	Set/ Full Sc.	max	Pr2
S1C	Action type output	in= Inverse; dir=direct	in	Pr2
Ac	Anti-short cycle delay:	0÷250 sec	0	Pr2
on	Minimum time a stage stays switched ON	0÷250 sec	0	Pr2
ono	Minimum time between 2 following switching ON of the same load	0÷120 min	0	Pr2
ALC	Alarm configuration	rE=relat.; Ab= absolute	rE	Pr2
ALL	Minumum alarm (ALC=rE) (ALC=Ab)	0 ÷ Start Sc.-Set Start Sc.÷ ALu	10.0/ 20	Pr2
ALU	Maximum alarm (ALC=rE) (ALC=Ab)	0 ÷ Full Sc.-Set ALL÷ Full Scale	10.0/ 20	Pr2
ALH	Alarm recovery differential	0÷Full scale	2.0/4	Pr2
ALd	Alarm delay	0÷999 min	15	Pr2
dAO	Alarm delay at start up	0÷23h 50min	1.3	Pr2
So1	Output status with faulty pr.	oFF=open on=closed	oFF	Pr2
tbA ¹	Alarm relay disabling	no; yES	yES	Pr2
AS ¹	Alarm relay polarity	CL÷oP	oP	Pr2
Lci ²	Start scale with current or voltage input	-1999÷1999	various	Pr1
Uci ²	End scale with current or voltage input	-1999÷1999	various	Pr1
OPb	Probe calibration	-Full Sc./ Full Sc.	0.0	Pr1
rES	Resolution	in=NO; dE=0,1; cE=0,01	in	Pr2
UdM	Measurement unit (temp.) (current/voltage)	°C=°C; °F= °F; 0=°C; 1=°F; 2=RH; 3=bar; 4=PSI, 5=off	various	Pr1
PbC	Kind of probe	Pt=Pt100; J=tcJ; c= tck; S=tcS; Ptc=PTC; ntc= NTC; 0-1=0÷1V; 10= 0÷10V; cur=0÷20mA	various	Pr1
P3F	3 rd wire presence	no=2 wires; yES=3 wires	no	Pr2
HES	Energy saving differential	Down Sc./ Full Sc.	0.0	Pr2
i1F	Digital input configuration	c-H / oFF / AuS / HES / EAL / bAL	EAL	Pr2
i1P	Digital input polarity	cL=closed; oP=open	cL	Pr2
did	Alarm delay for dig. input	0÷120m	0	Pr2
Adr	Serial address	0÷247	1	Pr2
OnF	oFF function enabling	no=not enabled; yES=enabled	no	Pr2
Ptb	Parameter table	Readable only	--	Pr2
rEL	Software release	Readable only	--	Pr2
Pr2	To access the Pr2	Readable only	321	Pr1

¹ Only for XT111C; ² Only for instrument with 4÷20mA or 0÷1V or 0÷10V

Evco S.r.l. • Code 104K412A00

EVK412 Two outputs digital thermoregulator for general purposes

GB ENGLISH



1 GETTING STARTED

1.1 Important

Read these instructions carefully before installing and using the instrument and follow all additional information for installation and electrical connection; keep these instructions close to the instrument for future consultations.

1.2 Installing the instrument

Panel mounting, with click brackets (supplied by the builder); dimensions in mm (in).




Additional information for installation:

- 59.0 (2.322) is the maximum depth with screw terminal blocks
- 83.0 (3.267) is the maximum depth with extractable terminal blocks
- the panel thickness must not be higher than 8.0 mm (0.314 in)
- working conditions (working temperature, humidity, etc.) must be between the limits indicated in the technical data
- do not install the instrument close to heating sources (heaters, hot air ducts, etc.), devices provided with big magnets (big speakers, etc.), locations subject to direct sunlight, rain, humidity, dust, mechanical vibrations or bumps
- according to the safety legislation, the protection against electrical parts must be ensured by a correct installation of the instrument; the parts that ensure the protection must be installed so that you can not remove them if not by using a tool.

1.3 Wiring diagram

With reference to the wiring diagram:

- the serial port (by request) is the port for the communication with the supervision system (through a serial interface, via TTL, with MODBUS communication protocol) or with the programming key; the port must not be used at the same time for the same purposes.



Additional information for electrical connection:

- do not operate on the terminal blocks with electrical or pneumatic screwdrivers
- if the instrument has been moved from a cold location to a warm one, the humidity could condense on the inside; wait about an hour before supplying it

- test the working power supply voltage, working electrical frequency and working electrical power of the instrument; they must correspond with the local power supply
- disconnect the local power supply before servicing the instrument
- do not use the instrument as safety device
- for repairs and information on the instrument please contact Evco sales network.

2 USER INTERFACE

2.1 Turning on/off the instrument

To turn on the instrument you have to supply it; to turn it off it is enough to cut off the power supply.

2.2 The display

If the instrument is turned on, during the normal operation the display will show the quantity you have set with parameter P5:

- if P5 = 0, the display will show the room temperature
- if P5 = 1, the display will show the first working setpoint.

2.3 Showing the room temperature

- make sure the keyboard is not locked and no procedure is running

press **set** 2 s: the display will show "Pb1"

press **set**

To quit the procedure:

- press **set** or do not operate 60 s
- press **set** or **set** as long as the display shows the quantity you have set with parameter P5 or do not operate 60 s.

2.4 Locking/unlocking the keyboard

To lock the keyboard:

- make sure no procedure is running
- press **set** and **set** 2 s: the display will show "Loc" 1 s.

If the keyboard is locked, you will not be allowed to:

- modify the working setpoints with the procedures related in paragraphs 4.1 and 4.2 (you also can modify the working setpoints through parameters SP1 and SP2).

This operation provokes the visualization of the label "Loc" 1 s.

To unlock the keyboard:

- press **set** and **set** 2 s: the display will show "UnL" 1 s.

2.5 Silencing the buzzer


- make sure no procedure is running
- press a button (the first pressure of the button does not provoke its usual effect).

3 OPERATION

3.1 Preliminary information

The operation mainly depends on parameter CFG.

3.2 Operation with parameter CFG = 1 (the first working setpoint is independent and the second one is relative to the first)




If parameter CFG has value 1, you can set the second working setpoint through parameter SP2 only (because it is relative to the first one).

You can get each load to work for cooling (parameters r5 and r10 = 0) or for heating (parameters r5 and r10 = 1).

In this example load 1 works for cooling, load 2 works for heating and the second working setpoint has a negative value.


3.3 Operation with parameter CFG = 2 (two independent working setpoints)



If parameter CFG has value 2, you can get each load to work for cooling (parameters r5 and r10 = 0) or for heating (parameters r5 and r10 = 1).

In this example load 1 works for cooling and load 2 works for heating.


3.4 Operation with parameter CFG = 3 (neutral zone)



If parameter CFG has value 3, the second working setpoint will not be available and parameters SP2, r5, r7, r8, r9 and r10 will not be significant.

Load 1 always works for cooling and load 2 always works for heating.

3.5 Operation with parameter CFG = 4 (two steps)



If parameter CFG has value 4, the second working setpoint will not be available and parameters SP2, r0, r6, r7, r8, r9 and r10 will not be significant.

You can get each load to work for cooling (parameter r5 = 0) or for heating (parameter r5 = 1); parameter r5 sets the action for each load. In this example each load works for cooling.

4 SETTINGS

4.1 Setting the first working setpoint

- make sure the keyboard is not locked and no procedure is running
- press **set** LED out 1 will flash
- press **set** or **set** in 15 s; also look at parameters r1, r2 and r3
- do not operate 15 s.

You also can modify the first working setpoint through parameter SP1.

4.2 Setting the second working setpoint

- press **set** during the modification of the first working setpoint: LED out 2 will flash
- press **set** or **set** in 15 s; also look at parameters r7, r8 and r9
- press **set** or do not operate 15 s.

You also can modify the second working setpoint through parameter SP2.

If parameter CFG has value 1, you can set the second working setpoint through parameter SP2 only (because it is relative to the first one).

If parameter CFG has value 3 or 4, the second working setpoint will not be available.

4.3 Setting configuration parameters

To gain access the procedure:

- make sure no procedure is running
- press **set** and **set** 4 s: the display will show "PA"
- press **set** or **set** in 15 s to set "19"
- press **set** or do not operate 15 s
- press **set** and **set** 4 s: the display will show "SP1".

To select a parameter:

- press **set** or **set**

To modify a parameter:

- press **set**
- press **set** or **set** in 15
- press **set** or do not operate 15 s

To quit the procedure:

- press **set** and **set** 4 s or do not operate 60 s.

Switch off/on the power supply of the instrument after the modification of the parameters.

4.4 Restoring the default value of configuration parameters

- make sure no procedure is running
- press **set** and **set** 4 s: the display will show "PA"
- press **set**
- press **set** or **set** in 15 s to set "743"
- press **set** or do not operate 15 s
- press **set** and **set** 4 s: the display will show "dEF"
- press **set**
- press **set** or **set** in 15 s to set "149"

- press **[set]** or do not operate 15 s: the display will show “dEF” flashing 4 s, after which the instrument will quit the procedure
- switch off/on the power supply of the instrument.

Make sure the default value of the parameters is appropriate, in particular if the probes are NTC probes.

5 SIGNALS

5.1 Signals

LED	MEANING
out 1	LED load 1 if it is lit, load 1 will be turned on if it flashes: • the modification of the first working setpoint will be running • a load 1 protection will be running (parameters C1 and C2)
out 2	LED load 2 if it is lit, load 2 will be turned on if it flashes: • the modification of the second working setpoint will be running • a load 2 protection will be running (parameters C7 and C8)
	LED alarm if it is lit, an alarm will be running
°C	LED Celsius degree if it is lit, the unit of measure of the temperatures will be Celsius degree (parameter P2)
°F	LED Fahrenheit degree if it is lit, the unit of measure of the temperatures will be Fahrenheit degree (parameter P2)
CODE	MEANING
Loc	the keyboard and/or the working setpoints are locked (parameters r3 and/or r9); also look at paragraph 2.4

6 ALARMS

6.1 Alarms

CODE	MEANING
AL1	First temperature alarm Remedies: • check the room temperature • look at parameters A1 and A3 Effects: • no effect
AL2	Second temperature alarm Remedies: • check the room temperature • look at parameters A5 and A7 Effects: • no effect

When the cause that has provoked the alarm disappears, the instrument restores the normal operation.

7 INTERNAL DIAGNOSTICS

7.1 Internal diagnostics

CODE	MEANING
Pr1	Room probe error Remedies: • look at parameter P0 • check the integrity of the probe • check the connection instrument-probe • check the room temperature Effects: • load 1 activity will depend on parameter C6 • load 2 activity will depend on parameter C10

When the cause that has provoked the alarm disappears, the instrument restores the normal operation.

8 TECHNICAL DATA

8.1 Technical data

Box: self-extinguishing grey.

Frontal protection: IP 65.

Connections: screw terminal blocks (power supply, input and outputs), 6 poles connector (serial port; by request); extractable terminal blocks (power supply, input and outputs) by request.

Working temperature: from 0 to 55 °C (32 to 131 °F, 10 ... 90% of relative humidity without condensate).

Power supply: 230 VAC, 50/60 Hz, 3 VA (approximate); 115 VAC or 12-24 VAC/DC or 12 VAC/DC by request.

Alarm buzzer: by request.

Measure inputs: 1 (room probe) for PTC/NTC probes.

Working range: from -50.0 to 150.0 °C (-50 to 300 °F) for PTC probe, from -40.0 to 105.0 °C (-40 to 220 °F) for NTC probe.

Resolution: 0.1 °C/1 °C/1 °F

Digital outputs: 2 relays:

- **load 1 relay:** 16 res. A @ 250 VAC (change-over contact).
- **load 2 relay:** 8 res. A @ 250 VAC (change-over contact).

The maximum current allowed on the loads is 10 A.

Serial port: port for the communication with the supervision system (through a serial interface, via TTL, with MODBUS communication protocol) or with the programming key; by request.

① ITALIANO

1 PREPARATIVI

1.1 Importante

Leggere attentamente queste istruzioni prima dell'installazione e prima dell'uso e seguire tutte le avvertenze per l'installazione e per il collegamento elettrico; conservare queste istruzioni con lo strumento per consultazioni future.

1.2 Installazione

A pannello, con le staffe a scatto in dotazione (si vedano i disegni del paragrafo 1.2 della sezione in Inglese).

Avvertenze per l'installazione:

- 59,0 è la profondità massima con morsettiere a vite
- 83,0 è la profondità massima con morsettiere estraibili
- lo spessore del pannello non deve essere superiore a 8,0 mm
- accertarsi che le condizioni di lavoro (temperatura di impiego, umidità, ecc.) rientrino nei limiti indicati nei dati tecnici
- non installare lo strumento in prossimità di fonti di calore (resistenze, condotti dell'aria calda, ecc.), di apparecchi con forti magneti (grossi diffusori, ecc.), di luoghi soggetti alla luce solare diretta, pioggia, umidità, polvere eccessiva, vibrazioni meccaniche o scosse
- in conformità alle normative sulla sicurezza, la protezione contro eventuali contatti con le parti elettriche deve essere assicurata mediante una corretta installazione dello strumento; tutte le parti che assicurano la protezione devono essere fissate in modo tale da non poter essere rimosse senza l'aiuto di un utensile.

1.3 Collegamento elettrico

Si veda il disegno del paragrafo 1.3 della sezione in Inglese.

Con riferimento allo schema elettrico:

- la porta seriale (su richiesta) è la porta per la comunicazione con il sistema di supervisione (attraverso un'interfaccia seriale, via TTL, con protocollo di comunicazione MODBUS) o con la chiave di programmazione; la porta non deve essere utilizzata contemporaneamente per i due scopi.

Avvertenze per il collegamento elettrico:

- non operare sulle morsettiere utilizzando avvitatori elettrici o pneumatici
- se lo strumento è stato portato da un luogo freddo a uno caldo, l'umidità potrebbe condensare all'interno; attendere circa un'ora prima di alimentarlo
- accertarsi che la tensione di alimentazione, la frequenza e la potenza elettrica operativa dello strumento corrispondano a quelle dell'alimentazione locale
- disconnettere l'alimentazione prima di procedere con qualunque tipo di manutenzione
- non utilizzare lo strumento come dispositivo di sicurezza
- per le riparazioni e per informazioni riguardanti lo strumento rivolgersi alla rete di vendita Evco.

2 INTERFACCIA UTENTE

2.1 Accensione/spengimento dello strumento

Per accendere lo strumento è necessario alimentarlo; per spegnerlo basta togliere l'alimentazione.

2.2 Il display

Se lo strumento è acceso, durante il normale funzionamento il display visualizzerà la grandezza stabilita con il parametro P5:

- se P5 = 0, il display visualizzerà la temperatura dell'ambiente
- se P5 = 1, il display visualizzerà il primo setpoint di lavoro.

2.3 Visualizzazione della temperatura dell'ambiente

• assicurarsi che la tastiera non sia bloccata e che non sia in corso alcuna procedura

- premere **[▼]** per 2 s: il display visualizzerà “Pb1”

- premere **[set]**

Per uscire dalla procedura:

- premere **[set]** o non operare per 60 s
- premere **[▲]** o **[▼]** fino a quando il display visualizza la grandezza stabilita con il parametro P5 o non operare per 60 s.

2.4 Blocco/sblocco della tastiera

Per bloccare la tastiera:

- assicurarsi che non sia in corso alcuna procedura

- premere **[set]** e **[▼]** per 2 s: il display visualizzerà “Loc” per 1 s.

Se la tastiera è bloccata, non sarà consentito:

- modificare i setpoint di lavoro con le procedure indicate nei paragrafi 4.1 e 4.2 (i setpoint di lavoro sono impostabili anche attraverso i parametri SP1 ed SP2).

Questa operazione provoca la visualizzazione della label “Loc” per 1 s.

Per sbloccare la tastiera:

- premere **[set]** e **[▼]** per 2 s: il display visualizzerà “UnL” per 1 s.

2.5 Tactitazione buzzer

- assicurarsi che non sia in corso alcuna procedura

- premere un tasto (la prima pressione del tasto non provoca l'effetto associato).

3 FUNZIONAMENTO

3.1 Cenni preliminari

Il funzionamento dipende principalmente dal parametro CFG.

3.2 Funzionamento con parametro CFG = 1 (il primo setpoint di lavoro è indipendente e il secondo è relativo al primo)

Si veda il disegno del paragrafo 3.2 della sezione in Inglese.

Se il parametro CFG è impostato a 1, il secondo setpoint di lavoro è impostabile solo attraverso il parametro SP2 (perché è relativo al primo).

È possibile far funzionare ciascun carico per freddo (parametri r5 e r10 = 0) o per caldo (parametri r5 e r10 = 1).

Nell'esempio il carico 1 funziona per freddo, il carico 2 funziona per caldo e il secondo setpoint di lavoro ha un valore negativo.

3.3 Funzionamento con parametro CFG = 2 (due setpoint di lavoro indipendenti)

Si veda il disegno del paragrafo 3.3 della sezione in Inglese.

Se il parametro CFG è impostato a 2, è possibile far funzionare ciascun carico per freddo (parametri r5 e r10 = 0) o per caldo (parametri r5 e r10 = 1).

Nell'esempio il carico 1 funziona per freddo e il carico 2 funziona per caldo.

3.4 Funzionamento con parametro CFG = 3 (zona neutra)

Si veda il disegno del paragrafo 3.4 della sezione in Inglese.

Se il parametro CFG è impostato a 3, il secondo setpoint di lavoro non sarà disponibile e i parametri SP2, r5, r7, r8, r9 e r10 non saranno significativi.

Il carico 1 funziona sempre per freddo e il carico 2 funziona sempre per caldo.

3.5 Funzionamento con parametro CFG = 4 (due gradini)

Si veda il disegno del paragrafo 3.5 della sezione in Inglese.

Se il parametro CFG è impostato a 4, il secondo setpoint di lavoro non sarà disponibile e i parametri SP2, r0, r6, r7, r8, r9 e r10 non saranno significativi.

È possibile far funzionare ciascun carico per freddo (parametro r5 = 0) o per caldo (parametro r5 = 1); il parametro r5 stabilisce il funzionamento per ciascun carico.

Nell'esempio ciascun carico funziona per freddo.

4 IMPOSTAZIONI

4.1 Impostazione del primo setpoint di lavoro

- assicurarsi che la tastiera non sia bloccata e che non sia in corso alcuna procedura
- premere **[set]** il LED **out 1** lampeggerà
- premere **[▲]** o **[▼]** entro 15 s; si vedano anche i parametri r1, r2 ed r3

- non operare per 15 s.

È inoltre possibile impostare il primo setpoint di lavoro attraverso il parametro SP1.

4.2 Impostazione del secondo setpoint di lavoro

- premere **[set]** durante la modifica del primo setpoint di lavoro: il LED **out 2** lampeggerà
- premere **[▲]** o **[▼]** entro 15 s; si vedano anche i parametri r7, r8 ed r9

- premere **[set]** o non operare per 15 s.

È inoltre possibile impostare il secondo setpoint di lavoro attraverso il parametro SP2.

Se il parametro CFG è impostato a 1, il secondo setpoint di lavoro è impostabile solo attraverso il parametro SP2 (perché è relativo al primo).

Se il parametro CFG è impostato a 3 o 4, il secondo setpoint di lavoro non sarà disponibile.

4.3 Impostazione dei parametri di configurazione

Per accedere alla procedura:

- assicurarsi che non sia in corso alcuna procedura
- premere **[▲]** e **[▼]** per 4 s: il display visualizzerà “PA”
- premere **[set]**
- premere **[▲]** o **[▼]** entro 15 s per impostare “-19”
- premere **[set]** o non operare per 15 s
- premere **[▲]** e **[▼]** per 4 s: il display visualizzerà “SP1”.

Per selezionare un parametro:

- premere **[▲]** o **[▼]**

Per modificare un parametro:

- premere **[set]**
- premere **[▲]** o **[▼]** entro 15 s
- premere **[set]** o non operare per 15 s.

Per uscire dalla procedura:

- premere **[▲]** e **[▼]** per 4 s o non operare per 60 s.

Interrompere l'alimentazione dello strumento dopo la modifica dei parametri.

4.4 Ripristino del valore di default dei parametri di configurazione

- assicurarsi che non sia in corso alcuna procedura
- premere **[▲]** e **[▼]** per 4 s: il display visualizzerà “PA”
- premere **[set]**
- premere **[▲]** o **[▼]** entro 15 s per impostare “743”
- premere **[set]** o non operare per 15 s
- premere **[▲]** e **[▼]** per 4 s: il display visualizzerà “dEF”
- premere **[set]**
- premere **[▲]** o **[▼]** entro 15 s per impostare “149”
- premere **[set]** o non operare per 15 s: il display visualizzerà “dEF” lampeggiante per 4 s, dopodiché lo strumento uscirà dalla procedura
- interrompere l'alimentazione dello strumento.

Accertarsi che il valore di default dei parametri sia opportuno, in particolare se le sonde sono di tipo NTC.

